

axl everfly - Quick Start Guide

Package Contents:

1* axl everfly 16S 35000mAh Battery

Installation

1. Connect main power cable AS150 to device's main power input



Safety Caution

- Use only a proper LiPo balance charger with correct cell (S) setting.
- Never charge unattended or on flammable surfaces.
- Do not charge above 4.2V per cell or discharge below 3.2V per cell.
- Do not use if the battery is swollen, damaged, or overheated.
- Avoid short circuits, water, and direct heat. Store in storage mode (3.8–3.85V/cell) when not in use.